



Thank you for purchasing the
Paracord Survival Keychain!

As a Thank You for choosing the Paracord
Survival Keychain, we would like to offer
you 10% off your next 1TAC.com purchase.
Use the code below for your next purchase
on our website:

THANKYOU10



User Manual

Paracord Survival Keychain





The 1Tac weatherproof **Paracord Keychain** is both functional and discreet. Fashioned from military-grade parachute cord, the 1Tac Survival Keychain has 7' of super strong, 550 test military spec paracord.

Paracord Survival Keychain Features:

- 7FT of 7-Strand Waterproof & Mildew Resistant Mil-Spec Parachute Cord
- Maximum Tension Resistance : 550lbs
- Survival Whistle
- Stainless Steel Carabiner Clip
- Stainless Steel Key Ring
- Durable Plastic Clasp
- Stainless Steel Striker/Cutter
- Rustproof Flint Fire Rod
- Emergency Whistle

To use Paracord Survival Keychain

How to unravel Survival Keychain:

1. Locate ends of paracord (next to key ring) by finding the small singed and melted ends.
2. Pull ends to release paracord by either pulling with your fingers or use a pair of pliers and work them loose by twisting back and forth.
3. Once loose, unravel cord by undoing each knot until you end up with a continuous string. It will take approximately 2-5 min to unravel.

4 Emergency uses for the Paracord:

1. Build a shelter – tie together branches or other debris.
2. Fishing Line – cut end of cord to expose the inner strands.
3. First Aid – use as an emergency tourniquet or suture.
4. Climbing – tested at 550lbs, it can be used as a climbing tool.

How to use Fire Starter:

The fire starter can be used when paracord has been unraveled or not. A benefit of starting a fire with an unraveled keychain is that the cord can be used as tinder for a fire by cutting a small 1 to 2 inch piece of the cord with the cutter/striker on keychain and using the inner strands.

1. Remove cutter/striker by pinching both sides of the end with the clasp and pull outward.
2. In a downward motion, strike rod on clasp with the steel striker to create a spark. Continue this motion until the spark creates a fire on your tinder.

Customer Support:

To reach our customer support staff Monday through Friday 8am - 4pm PST, email support@1tac.com or call 877-616-3515, press option 2.