



Thank you for purchasing the
Safety Charge!

As a Thank You for choosing the Safety Charge,
we would like to offer you 10% off your next
1TAC.com purchase. Use the code below for
your next purchase on our website:

THANKYOU10



User Manual

Safety Charge





With the **Safety Charge** device, you will always have an emergency radio, flashlight, siren, and device charger! Best of all, you will never have to worry about this running out of batteries.

Safety Charge Functions:

- 0.5W SMD and 2 LEDs Torch
- Hand Crank Mobile Charger
- Siren
- Tuning FM Radio

Safety Charge Features:

- Hand Crank generates power or Type A USB input charging
- High dB Siren Alarm
- Lighting Mode: 2 LEDs-0.5W SMD-Off
- Hand Crank Mobile Charger
- Battery Power Key Switch

To Operate Safety Charge:

Lighting: Press the “Light Power” switch to turn on or off

Radio: Turn “Radio Switch” to turn on or off and adjust volume

Tuning Radio: Press “+” or “-” to select channel

Siren: Press the “Siren” button to turn on or off

Built-in USB Charge: Turn **on** the on/off switch on the bottom and connect built-in USB with external 5V power

Charge Cell phone with Crank: Turn **off** the bottom on/off switch make sure cell phone power is off. Crank handle around 2 revolutions per second. 10 Minutes of continuous cranking will generate enough power to increase cell phone battery energy by 1%

Charge Built-in battery with Crank: Turn **on** the on/off switch on the bottom and crank handle around 2 revolutions per second. 1 minute of continuous ranking can make the two small LEDs light or radio run for 10 minutes.

Cautions:

- Do not look directly into the LED as this may cause damage to your eyes.
- This product is not a toy
- Contains small parts not suitable for children under 5 years of age
- Turn off the light when input charge

Customer Support:

To reach our customer support staff Monday through Friday 8am - 4pm PST, email support@1tac.com or call 877-616-3515, press option 2.