



Thank you for purchasing
The Striker!


As a Thank You for choosing The Striker,
we would like to offer you 10% off your
next 1TAC.com purchase. Use the code
below for your next purchase on our
website:

THANKYOU10



User Manual

The Striker





The Striker Features:

1. Works in wet/moist conditions or low temperatures
2. Each match is capable of over 15,000 burning strikes
3. Lightweight, space-saving and easy to carry
4. A necessary survival tool for outdoor camping, traveling, hiking etc
5. Waterproof
6. Safe and easy to use
7. Simple to operate. Works just like a normal match
8. Unlike a flint it produces an actual flame not just a spark

How to use The Striker:

1. Unscrew the match stem and fill the canister $\frac{3}{4}$ full with lighter fluid (making sure to avoid spilling).
2. Place the match stem back into the canister for a few moments so the wick at the end of match can absorb the lighter fluid.
3. Pull the match stem out and strike it on the side of the canister (away from your body to avoid the sparks) like it is a regular match.
4. When finished, blow out the match and replace the match stem back into the canister.
5. Screw the match stem down tightly so the lighter fluid doesn't leak or evaporate.

For Best Results:

1. Do not burn the match for more than 10 seconds at a time.
2. Make sure to fully tighten the match stem in the canister after each use. Failure to do this will allow leakage of the fluid.
3. Do not overfill the canister as this can cause spillage when you insert the match stem.
4. Never return the match stem to the canister while still lit.
5. Make sure the match is well-saturated. If the match is not well saturated, this could ruin the tool.
6. Always extinguish the flame beforehand. Failure to do so can result in damage to the tool and potential harm to the user.

Customer Support:

To reach our customer support staff Monday through Friday 8am - 4pm PST, email support@1tac.com or call 877-616-3515, press option 2.